





Návod na montáž
SK-Q8 80, SK-Q8 90
(SK-HQ8 80, SK-HQ8 90)




800



900




1000




Číslo položky	Nákres	Veľkosť (mm)	Počet
01			1
02			2
03			1
04			2
05		2.8mm	1
06			1
07			6
08		ST3.9X35	6
09		ST3.5X9.5	6
10			12
11			12
12		800-L	1
13		800-R	1
14		900-L	1
15		900-R	1
16		1000-L	1
17		1000-R	1


Potrebné náradie:




1




2







3




4







10



06

02

